


REPAIR PARTS

MURRAY GO-KART


MODEL GT60301A



REPAIR PARTS

MURRAY GO-KART

MODEL GT60301A



REPAIR PARTS

MURRAY GO-KART

MODEL GT60301A

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Seat	680192	31	Seat Belt	680062
2	Frame Assembly, Seat	680040E700	32	Tie	71372
3	Bolt, Carriage	2x84	33	Washer	17x53 Z
4	Bolt	1x163	34	Bolt, Shoulder	1x87
5	Lockwasher	18x32	35	Nut	15x82
6	Wire, Kill	680092	36	Screw	26x245
7	Switch, ON/OFF	23665	37	Fender, Right	680034E700
8	Washer	19x40	38	Cable, Throttle	680093
9	Nut	91489	39	Reflector	680059
10	Cap, Ignition	91488	40	Lockwasher	18x16
11	Key	672220	41	Nut, Flange	15x79
12	Frame Tube	680016E700	42	Engine (TEC)	<i>0HH60-71106C</i>
13	Belt, Seat	680062	43	Bracket, Chain Guard	680091E701
14	Bolt, Carriage	2x83	44	Washer	17x37
15	Frame Tube, Rear	680018E700	45	Bolt, Shoulder	1x90
16	Bracket, Flag	680036 Z	46	Screw	26x259
17	Pad, Tube (13 inches)	680077	47	Locknut	15x116
18	Pad, Tube (10 inches)	680079	48	Washer	17x45 Z
19	Nut	15x41	49	Bolt, Grease Fitting	680104
20	Lockwasher	18x33	50	Guard, Chain	680030E701
21	Locknut	15x123	51	Clutch, Centrifugal	680061
22	U-Tube Assembly	680010E700	52	Spacer, Clutch	92280
23	Washer	17x44	53	Bracket, Chain Guard	680025E701
24	Bolt, Shoulder	1x157	54	Screw	1x62
25	Locknut	15x84	63	Spring	165x129
26	Nut, Barrel	15x133	64	Arm, Pivot	24502 Z
27	Headrest	680193	65	Spacer	671914
28	Tube, Cross Brace	680011E700	66	Idler, Chain	680086
29	Bolt	1x125	67	Chain, #40 (36" Long)	680152
30	Washer	17x103	68	Bolt	1x108

REPAIR PARTS

MURRAY GO-KART

MODEL GT60301A

Key No.	Description	Part No.	Key No.	Description	Part No.
69	Washer	18x31	93	Floormat	680087
70	Pin, Cotter	30x49	94	Plug, End	680081
71	Nut	15x76	95	Chassis and Frame Assembly	776922E700
72	Nut, Flange	15x68	96	Spindle Assembly, Left	680159E700
73	Sprocket	680153	97	Fitting, Lub	92530
74	Bracket, Drum	680154	98	End, Tie Rod	680070
75	Brake, Band	680156	99	Locknut	15x33
76	Pin, Cotter	30x20	100	Rod, Left Tie	680084 Z
77	Rod, Rear Brake	680101E700	102	Bolt, Shoulder	1x111
78	Fender, Left	680035E700	103	Rod, Right Tie	680085 Z
79	Drive Wheel and Tire, Left	680151	104	Spindle Assembly, Right	680158E700
--	Tire 15 x 6.00-6	407924	105	Pedal, Accelerator	680120 Z
--	Tube	407047	106	Rod, Accelerator	680029E700
--	Valve Stem	24373	107	Bolt	1x71
80	Bolt, Carriage	2x77	108	Pad, Tube (6 inches)	680080
81	Front Wheel and Tire Assembly	680155	109	Wheel, Steering	680065
--	Tire 11 x 4.00-5	776902	110	Cap, Steering Wheel	680060
--	Tube	776903	111	Screw	26x285
--	Valve Stem	24373	112	Drive Wheel and Tire, Right	680150
82	Nut, Axle	15x128	--	Tire 15 x 6.00-6	407924
83	Bolt	1x131	--	Tube	407047
84	Washer	17x47 Z	--	Valve Stem	24373
85	Knob	680103	113	Bearing, Front Wheel	680106
86	Spring	164x32	116	Flag	680073
87	Bolt, Shoulder	1x120	117	Floorpan, Front	680114E700
88	Rod, Front Brake	680028E700	118	Washer	17x197
89	Pedal, Brake	680121 Z	119	Bearing, Rear Wheel	680160
90	Locknut	15x89	120	Key, Square	21553
91	Locknut	15x88	121	Axle	680131
92	Bolt, Shoulder	1x159	--	Book, Instruction	F-99301
			--	Parts Bag	680128

* Parts are available from a Authorized Engine Service Center. See "Engines, Gasoline" or "Gasoline Engines" in the yellow pages of the telephone directory.