


REPAIR PARTS

MURRAY GO-KART BODY

MODEL GT60501x92A



REPAIR PARTS

MURRAY GO-KART BODY


MODEL GT60501x92A

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Frame Tubes	680182E549	21	Seat	680257
2	Nut, Barrel	15x133	22	Frame Assembly, Seat	680178E549
3	Bolt, Carriage	2x77	23	Nut, Flange	17x79
4	Tube, Cross Brace	680189E549	24	Bracket, Seat Adjustment	680164
5	Pad, Tube	680267	25	Washer	18x32
6	Pad, Tube	680266	26	Bolt, Shoulder	1x87
7	Nut, Flange	15x89	27	Washer	17x53 Z
8	Bracket, Flag	680036 Z	28	Bolt, Carriage	2x64
9	Nut, Flange	15x41	29	Nut, Flange	15x84
10	Washer	18x33	31	Chassis and Frame Assembly	680220E549
11	Frame Tube, Rear	680188E549	32	Fender, Left	680224
12	Nut	15x123	33	Screw	26x249
13	U-Tube Assembly	680217E549	34	Tube, Bottom	680168E549
14	Belt, Seat	680270	35	Nut, Flange	15x88
15	Washer	17x103	36	Screw	26x263
16	Bolt	1x125	37	Floorpan, Front	680195E549
17	Washer	17x44	38	Fender, Right	680223
18	Bolt, Shoulder	1x120	39	Flag	680073
19	Nut, Flange	17x76	40	Wrench, Assembly	680232 Z
20	Headrest	680258	--	Book, Instruction	F-99302

REPAIR PARTS

MURRAY GO-KART DRIVE

MODEL GT60501x92A



REPAIR PARTS

MURRAY GO-KART DRIVE

MODEL GT60501x92A


Key No.	Description	Part No.	Key No.	Description	Part No.
1	Nut, Axle	15x126	31	Washer	17x53 Z
2	Washer	17x193	32	Pin, Cotter	30x20
3	Wheel and Tire Assembly, Rear	680237	33	Nut, Flange	15x84
--	Tire 18 x 9.50-8	776930	34	Brake, Disc	680242
--	Tube	407049	35	Bolt, Carriage	2x64
--	Valve Stem	24373	36	Bearing Assembly, Axle	680162
4	Tube, Axle Spacer	252x52 Z	37	Nut, Flange	15x88
5	Key, Square	680260	38	Spring, Extension	165x139
6	Cover, Chain	680227E700	39	Link	680252
7	Nut, Flange	15x128	40	Nut, Adjuster	21920
8	Sprocket	680163	41	Brake Assembly, Caliper	680243
9	Bearing	680161	42	Bracket, Brake	680244
10	Spacer, Bearing Tube	680249	43	Bolt	2x90
11	Nut, Flange	15x79	44	Cover, Torque Converter	680225
12	Key, Square	680259	45	Bolt	1x98
13	Shaft, Secondary Drive	680222	46	Spring	164x32
14	Cable, Accelerator	680093	47	Cover, Axle	680254
15	Axle	680247	48	Pin, Cotter	30x49
16	Screw	26x249	49	Rod, Brake	680261
17	Engine *	*	50	Nut, Flange	15x84
18	Plate, Torque Converter	680225E700	51	Bolt	1x108
19	Driver, Torque Converter	680167	52	Bolt	1x76
20	Washer	17x146 Z	53	Nut, Flange	15x89
21	Bolt	1x66	54	Pedal	21544
22	Lockwasher	18x15	55	Arm, Pedal	680223E700
23	Screw	1x62	56	Cover, Axle	680255
24	Lockwasher	18x16	57	Chain & Master Link	776925
25	Screw, Set	1x160	58	Bolt	1x160
26	Plate Assembly, Engine	680219E700	59	Rod, Accelerator	680262E700
27	Belt, Torque Converter	37x98	60	Sprocket	680221
28	Driven, Torque Converter	680166	61	Key, Square	680273
29	Nut, Flange	15x128	62	Washer	17x100
30	Chassis and Frame Assembly	680220E549	63	Washer	17x160

* Parts are available from an Engine Authorized Service Center. See "Engines, Gasoline" or "Gasoline Engines" in the yellow pages of the telephone directory.

REPAIR PARTS

MURRAY GO-KART STEERING

MODEL GT60501x92A



REPAIR PARTS

MURRAY GO-KART STEERING

MODEL GT60501x92A

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Wheel, Steering	680246	17	Washer	17x53
2	Bolt	1x71	18	End, Tie Rod	680070
3	Screw	26x285	19	Nut	15x33
4	Cap, Steering Wheel	680060	20	Nut, Flange	15x134
5	Nut	15x89	21	Bolt, Shoulder	1x167
6	Mat	680165	22	Bolt, Shoulder	1x108
7	Nut	15x41	23	Spring, Compression	164x33
8	Washer	17x102	24	Rod, Tie	680248 Z
9	Spindle Assembly, Left	680215E700	25	Bolt, Shoulder	1x87
10	Washer	17x100 Z	26	Spindle Assembly, Right	680214E700
11	Bearing	680106	27	Nut, Flange	15x112
12	Wheel and Tire, Front	680236	28	Strap, Tie	71372
	Tire 145 / 70-6	776931	29	Harness, Wire	680245
	Tube	407047	30	Switch, Recoil Start	23665
	Valve Stem	24373	31	Washer	19x40
13	Washer	17x197	32	Nut	91489
14	Nut, Axle	15x128	33	Cap	91488
15	Bolt, Shoulder	1x166	34	Key	67220
16	Nut, Flange	15x84			