


REPAIR PARTS

MURRAY GO-KART BODY

MODEL GT60501x92E



REPAIR PARTS

MURRAY GO-KART BODY


MODEL GT60501x92E

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Frame Tubes	680289E549	23	Nut, Flange	15x79
2	Nut, Barrel	15x135	24	Bracket, Seat Adjustment	680164
3	Bolt, Carriage	2x83	25	Washer	18x32
4	Tube, Cross Brace	680189E549	26	Bolt	1x87
5	Pad, Tube	680267	27	Washer	17x53 Z
6	Pad, Tube	680266	28	Bolt, Carriage	2x64
7	Nut, Flange	15x82	29	Nut, Flange	15x84
8	Bracket, Flag	680036 Z	31	Chassis and Frame Assembly	680220E549
9	Nut, Flange	15x136	32	Fender, Left	680224
10	Belt, Seat – Cable Anchor	680314	33	Screw	26x274
11	Frame Tube, Rear	680188E549	34	Tube, Bottom	680168E549
12	Nut	15x123	35	Nut, Flange	15x88
13	U-Tube Assembly	680217E549	36	Screw	26x263
14	Belt, Seat – Retractor	680316	37	Floorpan, Front	680195E549
16	Bolt, Shoulder	9x66	38	Fender, Right	680223
17	Washer	17x44	39	Flag	680073
18	Bolt	1x120	40	Wrench, Assembly	680230 Z
19	Nut, Flange	15x79	41	Wrench, Hex	680274
20	Headrest	680258	42	Bolt, Carriage	2x91
21	Seat	680301	43	Reflector	680059
22	Frame Assembly, Seat	680178E549	—	Book, Instruction	F-000307L

REPAIR PARTS

MURRAY GO-KART DRIVE

MODEL GT60501x92E



REPAIR PARTS

MURRAY GO-KART DRIVE

MODEL GT60501x92E


Key No.	Description	Part No.	Key No.	Description	Part No.
1	Nut, Axle	15x126	33	Nut, Flange	15x84
2	Washer	17x193	34	Brake, Disc	680242
3	Wheel and Tire Assembly, Rear	680237	35	Bolt, Carriage	2x64
—	Tire 18 x 9.50-8	776930	36	Bearing Assembly, Axle	680162
—	Tube	407049	37	Nut, Flange	15x88
—	Valve Stem	24373	38	Spring, Extension	165x139
4	Tube, Axle Spacer	252x53Z	39	Link	680252
5	Key, Square	680260	40	Nut, Adjuster	21920
6	Cover, Chain	680227	41	Brake Assembly, Caliper	680287
7	Nut, Flange	15x128		Pads, Caliper Brake	776938
8	Sprocket	680163	42	Bracket, Brake	680244
9	Bearing	680161	43	Bolt	2x90
10	Spacer, Bearing Tube	680249	44	Cover, Torque Converter	680225
11	Nut, Flange	15x79	45	Bolt	1x98
12	Key, Square	680259	46	Spring	164x32
13	Shaft, Secondary Drive	680222	47	Cover, Axle	680254
14	Cable, Accelerator	680093	48	Pin, Cotter	30x49
15	Axle	680317	49	Rod, Brake	680261E549
16	Screw	26x263	50	Nut, Flange	15x84
17	Engine *	*	51	Bolt, Shoulder	9x51
18	Plate, Torque Converter	680228E549	52	Bolt, Shoulder	9x65
19	Driver, Torque Converter	680167	53	Nut, Flange	15x89
20	Washer	17x146 Z	54	Pedal	21544
21	Bolt	1x66	55	Arm, Pedal	680286E549
22	Lockwasher	18x15	56	Cover, Axle	680255
23	Screw	1x62	57	Chain & Master Link	776925
24	Lockwasher	18x16	58	Bolt	1x160
25	Screw, Set	1x160	59	Rod, Accelerator	680262E549
26	Plate Assembly, Engine	680219E549	60	Sprocket	680221
27	Belt, Torque Converter	37x98	61	Key, Square	680260
28	Driven, Torque Converter	680166	62	Washer	17x100
29	Nut, Flange	15x128	63	Washer	17x192
30	Chassis and Frame Assembly	680220E549	64	Retainer	680122
31	Washer	17x53 Z	65	Screw	26x274
32	Pin, Cotter	30x20	66	Key	680273

* Parts are available from an Engine Authorized Service Center. See "Engines, Gasoline" or "Gasoline Engines" in the yellow pages of the telephone directory.

REPAIR PARTS

MURRAY GO-KART STEERING

MODEL GT60501x92E



REPAIR PARTS

MURRAY GO-KART STEERING

MODEL GT60501X92E

Key No.	Description	Part No.	Key No.	Description	Part No.
1	Wheel, Steering	680246	17	Washer	17x53 Z
2	Bolt	1x71	18	End, Tie Rod	680070
3	Screw	26x285	19	Nut	15x33
4	Cap, Steering Wheel	680060	20	Nut, Flange	15x134
5	Nut	15x89	21	Bolt	1x167
6	Mat	680165	22	Bolt	1x108
7	Nut	15x41	23	Spring, Compression	164x33
8	Washer	17x102	24	Rod, Tie	680248 Z
9	Spindle Assembly, Left	680215E549	25	Bolt	1x87
10	Spacer	740173	26	Spindle Assembly, Right	680214E549
11	Bearing	680106	27	Nut, Flange	15x112
12	Wheel and Tire, Front	680236	28	Strap, Tie	71372
	Tire 145 / 70-6	776931	29	Harness, Wire	680245
	Tube	407047	30	Switch, Recoil Start	23665
	Valve Stem	24373	31	Washer	19x40
13	Washer	17x197	32	Nut	91489
14	Nut, Axle	15x128	33	Cap	91488
15	Bolt	1x166	34	Key	672220
16	Nut, Flange	15x84			