


# BATTERY TRIMMER PARTS - MODEL 51330



Item	Part No.	Description	Item	Part No.	Description
1	180411	Battery Door	16	180518	Motor Supports (qty. 2)
2	180363	Battery Cushion Set (qty. 5)	17	180519	Motor
3	180513	Upper Wiring Harness Assembly	18	180372	Outer Spool and Eyelet (includes item 19)
4	180410	Battery	19	180373	Eyelet
5	180513	Lower Wiring Harness Assembly	20	180374	Spring
6	180538	Battery Housing W/Out Decals	21	180375	Screw
7	180151	Trigger	22	180292	Inner Reel and .065 Line
8	180364	Safety Release Switch	23	180376	Reel Cover
9	180150	Switch	24	180293	Guard and Blade Assembly (includes item 26)
10	180300	Housing Screw Set (qty. 11)	25	180520	Guard Mounting Screw and Washer Set
11	180367	Boom Assembly	26	180377	Blade Assembly
12	145819	D-Handle	27	180294	Battery Charger
13	153523	D-Handle Hardware	28	180295	Wall Station Assembly
14	180300	Housing Screw Set	29	180378	Wall Station Clamp and Screw
15	180539	Motor Housing	*	180117	Monofilament Cutting Line (50 ft.)
			*	180327	Cutting Head Assembly (includes items 18-23)
			*		not shown